



**1: When the vice is stiff, loosen the adjustable screws.  
When the vice is loose, tighten the adjustable screws.**